

Huawei AR169 – installation instructions

Required parts:-

- Huawei AR169 Router
- Power cable
- Yellow Straight-through RJ45 Ethernet Cable
- Green Crossover RJ45 Ethernet Cable



Connecting the router:-

Step 1. Plug the power cable into the router power socket labelled 4 in the below picture

Step 2. Plug the Green/red RJ45 Ethernet Crossover cable into port **GE0**, labelled 0 in the below picture and the other end of the same cable goes into the suppliers NTE device

Step 3. Connect your network device (eg. router, switch, laptop, firewall etc) to port **GE1** using the Yellow RJ45 Ethernet Straight-through cable.

NB. The top image (labelled 21CN) is the BT Openreach ADVA NTE ; the below image is a Alcatel-Lucent NTE, traditionally used by non-BT Openreach carriers (eg. Virgin media)

