

Juniper SRX300 – installation instructions

Required parts:-

- Juniper SRX300 Router
- Power cable
- 2 x straight-through RJ45 Ethernet Cables



Connecting the router:-

Step 1. Plug the power cable into the router power socket

Step 2. Plug the Ethernet cable into port **0/5** on SRX router and the other end of the same cable goes into the suppliers NTE device



Step 3. Connect your network device (eg. router, switch, laptop, firewall etc) to port **0/1**

